



# FLOOR PLAN

1/8" = 1'-0"

NEW DOWNSPOUT IN WALL  
NEW DRAIN UNDER WALK

RELOCATE DOWNSPOUT IN NEW WALL  
NEW DRAIN UNDER WALK

SIDE